

FAQ#78 Làm thế nào để đăng nhập vào giao diện cấu hình của N100RE & N200RE cho người dùng mới?


1. Kết nối máy tính của bạn với router bằng dây cáp.
2. Mở bất kỳ trình duyệt nào, truy cập vào 192.168.1.1



3. Điền **admin** vào User Name và Password, cả 2 đều không viết in hoa. Sau đó nhấn **LOGIN**.

USER LOGIN

The server 192.168.1.1 requires a username and password



User name: admin

Password: [REDACTED]

LOGIN

4. Trang **Easy Setup** sẽ xuất hiện cho việc cài đặt nhanh và cơ bản, bao gồm **Internet Setting** và **Wireless Setting**.

Easy Setup

The quick setup will guide you to configure access point for first time.

[Advanced Setup](#)

Connect Status

Connect Status: **Getting IP from DHCP server... Disconnected**

Internet Setting

WAN Access Type: **DHCP Client**

Wireless Setting

Disable Wireless: **Enable**

SSID: **TOTOLINK N100RE**

Encryption: **Open System**

[Apply](#)

[Reset](#)

5. Chọn **Advanced Setup**, bạn sẽ đến giao diện cấu hình của router



The screenshot shows the TOTO LINK web interface. The top header includes the TOTO LINK logo and the tagline "The Smartest Network Device". Below the header, there is a navigation menu on the left with options like System Status, Operation Mode, Network, Wireless Setting, Gels, Firewall, and Management. The main content area is titled "System Status" and contains a table of system configuration details.

System Configuration	
Uptime	00day:0h:7m:28s
Firmware Version	TOTOLINK-N188RC-V2.0-020140518-1313
Operating Mode	Gateway

WAN Configuration	
WAN MAC	7E:44:7E:45:96:00
obtain IP Protocol	Getting IP from DHCP server...
IP Address	0.0.0.0 / 0.0.0.0 / 0.0.0.0

LAN Configuration	
LAN MAC	7E:44:7E:45:96:00
obtain IP Protocol	Fixed IP
IP Address	192.168.1.1 / 255.255.255.0 / 192.168.1.1
DHCP Server	Enabled

Wireless Configuration	
------------------------	--